

# Wash basin IC1

**Art. no.** IC1-22  
**GTIN** 7393069022674  
**Ref. no** 642257000



|                                  |                |
|----------------------------------|----------------|
| <b>Overall dimension in mm</b>   | 525 x 334 x 97 |
| <b>Depth in mm</b>               | 97             |
| <b>Bowl dim. in mm</b>           | 500 x 310 x 83 |
| <b>Waste hole placement</b>      | C              |
| <b>Material</b>                  | AISI 304       |
| <b>Material thickness in mm</b>  | 0,9            |
| <b>Installation height in mm</b> | 850            |
| <b>Gross weight in kg</b>        | 2.31           |
| <b>Net weight in kg</b>          | 1.36           |
| <b>Weight, pallet</b>            | 94.30          |
| <b>Pcs per pallet</b>            | 30             |
| <b>Design</b>                    | Halvor Thorsen |

## Description

Icon Hand Wash Basin IC1-22 in stainless steel 18/10, is designed for under mounting. The hand wash basin is pressed in one piece and has laser-cut integrated outlet holes that are concealed by a removable outlet cover. The basin is supplied with waste under part and overflow equipment.

Polished finish.

## Installation

See the enclosed installation instruction.



# Installation IC1

## ASSEMBLY:

Included in the box:

Washstand

- \* Valve set with overflow
- \* Outlet cover
- \* Assembly instructions

Ensure that everything has been included in the box before starting assembly.

Use the supplied template for positioning and sawing the correct hole size in the countertop.

When mounting the overflow, do not use tools - just hand power. Mount the outlet parts and overflow onto the washstand before it is glued onto the countertop. Put the outlet cover in place to finish.

# Maintenance IC1

## SPARE PARTS:

Drain cover: ZICDEKSELLIMT  
Valve set with overflow 79145

## INTRA PRODUCTS OF STAINLESS STEEL

For all Icon wash basins: The outlet cover can be removed in order to clean the underside of the cover.

In order for your Intra stainless steel product in AISI304 to retain its original quality and appearance, we recommend regular cleaning. Use mild soap or cleaning products specifically designed for stainless steel and clean water. Then wipe the surface with a dry cloth.

Never use detergents containing chlorine, iodine, fluoride or abrasives on stainless steel. Also avoid contact with acid solutions and other substances incompatible with stainless steel. Remember that food and skin care products may contain such substances, e.g. ketchup, juice, salt, certain cleansers, nail polish, etc. Promptly remove spills of such

products.

Observe the following:

Do not allow water or other liquid to dry in. This is to avoid staining the surface.

Even though stainless steel can withstand harsh treatment, it can easily be scratched by sharp objects. For products with normal, polished (brushed) finish, this will be very visible when the product is new, but after a period of use, this will be negated as the steel loses its lustre. For products with satin and polished finishes, the scratches will always be visible.

Never use scouring powder or steel wool on stainless steel. In addition to scratching the steel, wire wool will leave behind small particles that may develop into rust spots which, over time, may corrode the steel.

Stainless steel must not come into contact with, or be in environments containing, chlorine solutions for long periods of time.

Silver polish causes stains which cannot be removed.