

Wash trough P180

Art. no. P180V
GTIN 7393069021387



| | |
|----------------------------------|------------------|
| Overall dimension in mm | 1800 x 430 x 335 |
| Waste hole placement | C |
| Material | AISI 304 |
| Material thickness in mm | 0,7 |
| Installation height in mm | 850 |
| Product load in N | 1000 |
| Gross weight in kg | 12.00 |
| Weight, pallet | 109.00 |
| Pcs per pallet | 7 |

Description

Fully pressed wash trough for wall mount. Supplied with wall brackets, wall panel and 1 1/2" grated waste.



Installation P180

ASSEMBLY:

Included in the box

- * Wash trough
- * Consoles x 2
- * Valve with dome grate waste 1 1/4" og 1 1/2"
- * Wall panel

Ensure that you have all the parts before assembly begins.

Fix the bracket to the wall and mount the wash trough onto the brackets. Fix the wall panel on top of the trough and to the wall.

SPARE PARTS:

Valve with dome grate 1 1/4" and 1 1/2": 79136
Wall panel: ZVBV180
Consoles (pair): 91104

MAINTENANCE:

In order for the product to retain its original quality and appearance, regular cleaning is recommended. Use mild soap or products specifically designed for

stainless steel and clean water. Then wipe the surface with a dry cloth. Never use detergents containing chlorine, iodine, fluoride or abrasives. Also avoid contact with acidic solutions and other substances incompatible with stainless steel. Remember that food stuffs and skin care products may contain such substances; e.g. ketchup, juice, salt, some cleansers, nail polish, etc. Promptly remove spills of such products.

* Do not allow water or other liquid to dry in. This is to avoid staining the surface.

* Even though stainless steel can withstand harsh treatment, it will easily be scratched by sharp objects. For products with polished (brushed) finishes, this will be very visible when the product is new, but after a period of use, this will be negated as the steel loses its lustre. On surfaces with satin and polished finishes, the scratches will always be visible. Never use scouring powder or steel wool on stainless steel. This will scratch the steel and steel wool will leave small particles that can develop into rust spots.

* Stainless steel must not come into contact with, or be in environments containing, chlorine solutions for long periods of time.

* Silver polish causes stains which cannot be removed.